


How to Update Reader Firmware:

- To begin, sign into your BadgePass ONE account and make your way to the devices drop-down menu.
- Select Readers
 - **Note:** This is where you can manage your readers and configure settings for each individual reader.
- Select the Specific Reader you want to view.
 - A flyout menu will appear showing you the status of the device.
 - If you see a red exclamation mark next to the firmware version this means a firmware update is available.
 - Select the settings button.
- The setting landing page will appear.
 - Here you will be able to locate your device details. Below that, you will see your Current Firmware and if you have any newer updates available. If you have a new update available, you can select Update firmware. Then Select "yes." This will initiate the update for your door reader.
 - **Note:** If this button is greyed out or not available, it means that your reader is up-to-date.



Device Overview ✕	
Name:	Demo Room NDEB
Serial Number:	A2000000F14B627
Model:	ndeb
Profile:	Weekday
Status:	Connected
Reader:	Firmware Version: 03.10.01 ! Last Communication: Apr 24, 2023, 3:25:03 AM Command Status: Ready Database Status: Good
Settings	